

## **FEATURES**

- Ergonomic design
- Australian output plugs
- · Wide input voltage range
- Boost and buck AVR
- Compatible with generators
- · Audible alarms function
- Full-time surge protection
- Automatic diagnostic on startup
- Cold start function
- · Intelligent battery management
- Automatic restart when mains returns
- · Automatic battery charging in UPS off mode
- USB / RS232 communications
- Supplied with intelligent monitoring and control software
- Protection against short circuit and low battery voltage

























Surveillance

illance Point of S

Systems

Computer Per










## **SPECIFICATIONS**

Model

| Model                           | Eco-Aito 1400   |  |  |  |  |  |
|---------------------------------|---|--|--|--|--|--|
| Capacity                        | 1400VA/840W   |  |  |  |  |  |
| Input                           |   |  |  |  |  |  |
| Voltage                         | 230/240V  |  |  |  |  |  |
| AVR voltage range               | 162V-290V   |  |  |  |  |  |
| Frequency range                 | 40Hz-70Hz   |  |  |  |  |  |
| Output                          |   |  |  |  |  |  |
| Voltage regulation              | Batt. mode: 230V ± 10%  |  |  |  |  |  |
| Frequency                       | 50 Hz ± 1Hz   |  |  |  |  |  |
| Waveform                        | AC mode: sine wave; Battery mode: simulated sinewave  |  |  |  |  |  |
| Transfer time                   | Typical 2-6ms   |  |  |  |  |  |
| Battery                         |   |  |  |  |  |  |
| Туре                            | Sealed lead acid, maintenance free  |  |  |  |  |  |
| Configuration                   | 2 x 12V/7.5AH   |  |  |  |  |  |
| Charge current(Max)             | 2A  |  |  |  |  |  |
| Backup time                     | > 6 minutes load dependent  |  |  |  |  |  |
| Recharge                        | 6-8 hours to 90% capacity after complete discharge  |  |  |  |  |  |
| Function                        |   |  |  |  |  |  |
| Communication                   | RS232 & USB   |  |  |  |  |  |
| Surge protection                | RJ45  |  |  |  |  |  |
| DC start                        | Yes   |  |  |  |  |  |
| Auto restart                    | Yes   |  |  |  |  |  |
| AVR                             | Yes   |  |  |  |  |  |
| Surge protection                | 720 Joules / 30000A   |  |  |  |  |  |
| Input protection                | EN50091-2 (C-Tick)  |  |  |  |  |  |
| Short circuit                   | User replaceble fuse  |  |  |  |  |  |
| LED indication & audible alarms | AC mode, battery charging, battery mode,<br>battery low, over temperature,<br>overload, short circuit |  |  |  |  |  |
| Environment                     |   |  |  |  |  |  |
| Audible noise                   | < 40dB  |  |  |  |  |  |
| Temperature                     | 0 - 40 Degrees C( non-condensing)   |  |  |  |  |  |
| Humidity                        | 0 - 90%   |  |  |  |  |  |
| Physical                        |   |  |  |  |  |  |
| Australian outlets              | 3   |  |  |  |  |  |
| Dimensions (WxDxH)              | 338x149.3x162mm   |  |  |  |  |  |
| Net weight                      | 8Kg   |  |  |  |  |  |
|                                 |   |  |  |  |  |  |

Eco-Alto 1400

## **BACK PANELS**



- 1 USB communication port
- 2 RJ11 surge protection
- 3 IEC input
- 4 User replaceble fuse
- 5 Output sockets
- 6 RS232 communication port
- 7 RJ45 surge protection

## **RUNTIME IN MINUTES**

| Load VA/W     | 100VA | 200VA | 400VA | 500VA | 600VA | 800VA | 1000VA | 1200VA |
|---------------|-------|-------|-------|-------|-------|-------|--------|--------|
|               | 60W   | 120W  | 240W  | 300W  | 360W  | 480W  | 600W   | 720W   |
| Eco-Alto 1400 | 91    | 60    | 32    | 28    | 23    | 15    | 10     | 7      |